

Important information: Determine your Model of Speed Saw to buy the right chain and bar.



Model 1

- Black chassis
- Guide bar 152 mm wide
- Chain with 88 DL



Model 2

- Black chassis
- Guide bar 133 mm wide
- Chain with 88 DL



Model 3

- White chassis
- Guide bar 133 mm wide
- Chain with 84 DL



MODEL 1



MODEL 2



MODEL 3

Speed Saw Model 1:

This saw requires a conversion kit (art. No. 6608-001-9999) and then the cutting equipment for model 2 fits.

Speed Saw Model 2:

Bar Speed Saw 50 cm Standard 3010-020-1050 (recommended length for Speed Saw)
Chain 88 dl 3614-000-0088

Bar Speed Saw 70 cm Standard 3010-020-3070
Chain 104 dl 3614-000-0104

Bar Saw Model 3:

Bar Speed Saw 50 cm Standard 3010-010-3050 (recommended length for Speed Saw)
Chain 84 dl 3614-000-0084

Bar Speed Saw 70 cm Standard 3010-010-3070
Chain 104 dl 3614-000-0104

Viktig information: Fastställ din modell av Speed Saw för att köpa rätt svärd & kedja.



Model 1

- Black chassis
- Guide bar 152 mm wide
- Chain with 88 DL



Model 2

- Black chassis
- Guide bar 133 mm wide
- Chain with 88 DL



Model 3

- White chassis
- Guide bar 133 mm wide
- Chain with 84 DL



152 mm, 88dl

MODEL 1



133 mm, 88dl

MODEL 2



133 mm, 84dl

MODEL 3

Speed Saw Modell 1:

För denna såg krävs en ombyggnadssats (art.nr 6608-001-9999) och då passar skärutrustningen till modell 2.

Speed Saw Modell 2:

Svärd Speed Saw 50 cm Standard 3010-020-1050 (rekommenderad längd för Speed Saw)
Kedja 88 dl 3614-000-0088

Svärd Speed Saw 70 cm Standard 3010-020-3070
Kedja 104 dl 3614-000-0104

Bar Saw Modell 3:

Svärd Speed Saw 50 cm Standard 3010-010-3050 (rekommenderad längd för Speed Saw)
Kedja 84 dl 3614-000-0084

Svärd Speed Saw 70 cm Standard 3010-010-3070
Kedja 104 dl 3614-000-0104